


FLOOR PLANS

LOW ZONE 8th Floor



THE SEASONS
RESIDENCES
HARU




FLOOR PLANS

LOW ZONE 9th - 23rd Floor



THE SEASONS
RESIDENCES
HARU




FLOOR PLANS

LOW ZONE 25th - 26th Floor



THE SEASONS
RESIDENCES
HARU



FLOOR PLANS

MID ZONE 27th - 39th Floor



THE SEASONS
RESIDENCES
HARU



E
2BR SUITE 89 sqm

F
2BR SUITE 85 sqm

G
2BR SUITE 84 sqm


H
2BR SUITE 92 sqm

D
2BR SUITE 91.5 sqm

C
2BR SUITE 78 sqm

B
2BR SUITE 93.5 sqm

A
2BR SUITE 84 sqm




FLOOR PLANS

HIGH ZONE 40th - 42nd Floor




THE SEASONS
RESIDENCES
HARU




LOWER LEVEL - 43rd Floor

UPPER LEVEL - 45th Floor



B
3BR
LL = 137 sqm
UL = 100 sqm
237 sqm



A
3BR
LL = 134 sqm
UL = 99 sqm
233 sqm

KEY PLAN

KEY PLAN